
Introduction of the cutting tools



Types and characteristics of cutting tools



Left 1: Special blade, cutting thickness: within 1.5mm. cutting materials: paperboard, Kraft paper, gray board offset board and self-adhesive paper.


Left 2: 39 blade, cutting thickness: Within 3mm. cutting materials: paperboard, Kraft paper, gray board, offset board, self-adhesive paper and compound materials.

Center: 26 blade, cutting thickness: Between 5mm and 7 mm. cutting materials: corrugated board, paperboard, Kraft paper, gray board, offset board, self-adhesive paper and compound materials.

Right 2: 20 blade, cutting thickness: Between 7mm and 10 mm. cutting materials: corrugated board, paperboard, Kraft paper, gray board, offset board, self-adhesive paper and compound materials.

Right 1: 16 blade, cutting thickness: Between 10mm and 15mm. cutting materials: corrugated board, paperboard, Kraft paper, gray board offset board, self-adhesive paper and compound materials. Note: blade can be changed according to different material and customers' requirement.

Types and characteristics of creasing tools



Left 1: 7mm press wheel, creasing thickness: Between 7mm and 10mm

Creasing material: Corrugated board.

Left 2: 5mm press wheel, creasing thickness: Between 5mm and 7mm

Creasing material: Corrugated board

Right 1: 3mm press wheel, creasing thickness: Between 3mm and 5mm


Creasing material: Corrugated board

Right 2: 2mm press wheel, creasing thickness: Within 2mm


Creasing materials: corrugated board, paperboard, Kraft

paper, gray board, offset board, self-adhesive paper and compound materials.

Adjust the depth of knife and press wheel



Install blade



correct (the edge is forth)

wrong (the edge is back)

The scrw can fix the blade Adjust the position of the knife (fix on the direction with the head of the machine) Fix the end of the knife and the head of the machine.

Install press wheel



Installation steps: 1. Aim the orientation slot at the orientation bolt, and push it up.

2. Put the circlip into the slot.

3. Adjust the creasing depth of the press wheel.