




How to adjust the depth

According to the following operation, the machine will be slotted




If you feel the cut depth is a little shallow or a little deep , you can adjust these parameter from this part

“craft parameter”---vert parameter (follow as picture)



1.About “slot deep adjust home correct” this parameter, if you feel both front side and back side are all deep or shallow , you can adjust this parameter

If deep, decrease this number, if shallow increase this number (little by little , for example 0.3)



About” front depth correct “, this parameter, if you feel just front side is shallow or deep , you can adjust this number (decrease or increase)

Because stainless model doesn’t have back cut ,so in this software ,it doesn’t show back depth correct(but in aluminum model, it has)

